

STILL SPIRITS

CREATE+ SIGHT GLASS BUBBLE PLATE

INSTRUCTIONS

ABOUT YOUR CREATE+ SIGHT GLASS BUBBLE PLATE

High Quality Construction

The Create+ Sight Glass Bubble Plate is constructed from high-quality materials ensuring durability and reliable performance. The bubble plate is made of copper, while the sight glass features a strong 304-grade stainless steel frame and borosilicate glass for clear visibility. This combination allows you to observe the distillation process in action giving you better control and insight into your run.

Compatible with the Create+ T500 Column & Condenser

The Create+ Sight Glass Bubble Plate is fitted with 2" tri-clamp ferrules, making it fully compatible with most 2" tri-clamp distilling systems, including the Create+ T500 Column & Condenser. Bubble plates are designed to promote reflux, helping to increase purity and separation during distillation*.

*Results may vary, depending on your individual set-up.



CLEANING: BEFORE FIRST USE

Rinse all components with fresh, clean water before the first distillation run.

ASSEMBLY

Ensure correct assembly as per below steps to prevent leakages which can be hazardous. If you notice any leaks during operation, turn off your heat source, let the sight glass cool down, and check for assembly issues.

- 1 Remove one of the sight glass ferrules by undoing the 4 dome nuts using a 10 mm wrench. Ensure the glass-to-ferrule seal ('L' profile seal) remains on the glass tube.
- 2 Place the bubble plate onto the glass-to-ferrule seal ensuring it is centred and oriented such that the stainless-steel liquid-guide ramp points upwards.
NOTE: For ease of assembly we are assembling everything upside down and will invert it afterwards.
- 3 Place the silicone flat seal onto the bubble plate ensuring it is also centred.
- 4 Replace the sight glass ferrule over the bubble plate and silicone flat seal.
- 5 Replace the 4 dome nuts ensuring each nut is tightened evenly and also ensuring not to overtighten. Tighten the 4 hex nuts immediately below the sight glass ferrule. To make sure the assembly is secure, you may need to adjust some threaded rods and/or other nuts.
- 6 Invert the assembled sight glass bubble plate and insert it into your distilling system ensuring silicone gaskets are placed in the tri-clamp connections. Secure with a tri-clamp.

CLEANING: AFTER USE

If needed, thoroughly rinse the sight glass bubble plate to remove any wash or debris. Use a non-scented brewery cleaner and a soft brush to remove any stubborn debris.

For a comprehensive clean of the bubble plate, recommended every 20 distillations, rinse the bubble plate with a citric acid mix (2 tsp citric acid to 1 L or 1 US qt of water) or soak for a few minutes. For tough stains, soak for up to 12 hours. Follow rinsing/soaking by flushing with water 2 or 3 times to eliminate any residual acid then allow to air dry thoroughly before storing.

**SCAN HERE TO EXPLORE THE
CREATE+ EQUIPMENT RANGE**



www.stillspirits.com